



Fructozym® Flow UF

Pure pectin methylesterase for fruit processing

Product description

Fructozym® Flow UF is a liquid, concentrated pectinase for improved stabilisation of fruit juices rich in colloids and to increase filter flux-rate during ultrafiltration.

Typical applications for Fructozym® Flow UF are:

- complete pectin degradation in juices as prerequisite for clarification and filtration
- improved stability for fruit juices rich in colloids due to intensive mash extraction measures
- no risk for an arabane after haze
- to increase flux-rate of ultrafiltration plants and to extend filtration cycle until the next necessary membrane cleaning
- degradation of foam stabilising components and filter inhibiting colloids for special applications (e.g. ajc for "Schorle")

Dosage

The required enzyme dosage depends on raw material, ripening, temperature and reaction time:

Guideline at 45 - 55 °C and 2 - 3 h reaction time:	
application	ml/1,000 l juice
apple juice rich in colloids	35
extraction juice from pome fruit pomace	35 - 70
coloured juice rich in colloids	35

Fructozym® Flow UF is added as a 20-50 fold dilution to the juice after pasteurisation.

Storage

Store in a cool and frost-free place. Use-up opened packages within a short time.